



## TECHNOLOGY GUIDE

# Sensors for AUV/ROV & Autonomous Platforms

Autonomous and remotely operated underwater vehicles are revolutionizing ocean science by accessing environments beyond the reach of traditional research methods. These platforms, equipped with high-precision sensors, enable real-time data collection while dramatically reducing operational costs.

## AUVs & ROVs: Unique Sensors for Unique Platforms

Autonomous and remotely operated underwater vehicles are rapidly evolving to fill scientific niches, many with capabilities otherwise unattainable through traditional manned research at a fraction of the operating cost. Sea-Bird Scientific offers a line of sensors uniquely designed for integration with a diverse array of unmanned underwater vehicles, expanding the data potential of underwater robots and opening new doors for unique research opportunities.

While the original Sea-Bird Scientific products were designed for shipboard profiling, redesign and miniaturization of popular product lines meets the operational requirements of unmanned research platforms while retaining the original data quality. A 1 kg CTD can now replace a 10 kg CTD while maintaining the same accuracy with drastically reduced power consumption. A precision optical sensor can now take up half the space while recording the same data channels. Autonomous Moving platform applications include Unmanned Surface Vehicles (USV), Autonomous Underwater Vehicles (AUV) such as gliders, and ROVs.

Acronym Key	
<b>AUV</b>	Autonomous Underwater Vehicle
<b>ROV</b>	Remotely Operated Underwater Vehicle
<b>UUV</b>	Unmanned Underwater Vehicle
<b>USV</b>	Unmanned Surface Vehicle
<b>CTD</b>	Conductivity Temperature Depth
<b>BGC Sensor</b>	Bio Geo Chemical Sensor



## Unmanned Surface Vehicles (USVs)

While moored buoy systems are valuable for time series data, unmanned surface vehicles (USV) widen the capabilities of autonomous sampling by skimming across the surface of the ocean, collecting high-quality data along the way. With relatively low-cost deployments, USVs can function like a shipboard thermosalinograph without the associated expenses, filling in data gaps between moorings and travelling to areas otherwise inaccessible by traditional research vessels.

USVs provide a flexible sampling platform—they are often outfitted with a variety of sensors for holistic sampling of surface data along with a real-time data link. Such automated systems allow scientists to deploy USVs for missions that are otherwise too dangerous or cost-prohibitive, and a flotilla of USVs has the potential to provide much greater surface coverage than ever before.



Photo: TAMU Geosciences Communications and Media Relations





## Case Study: Wave Glider in the Gulf of Mexico

Shortly after the wake of Hurricane Harvey in 2017, a USV began chasing after a dark underwater cloud in the Gulf of Mexico. The Gulf Explorer, a Liquid Robotics Wave Glider owned by Texas A&M's Geochemical and Environmental Research Group (GERG), was deployed on September 8th, 2017 equipped with sensors to measure several variables such as salinity and water temperature and the ability to transmit data back to shore every 30 minutes.

Its mission: to better understand and monitor freshwater flowing into the Gulf of Mexico from Hurricane Harvey's passage. Radiating from river deltas on the coast, this plume of freshwater threatened Flower Garden Banks National Marine Sanctuary, a protected coral reef ecosystem hosting breathtaking biodiversity. At the time of the deployment, it was unclear whether this freshwater plume would reach the sanctuary, and the potential impacts if it did.



Photo: TAMU Geosciences Communications and Media Relations

## AUVs and Gliders



Underwater vehicles have been undergoing a form of divergent evolution; the streamlined torpedo is giving way to designs that range from a winged squid to a miniature stealth bomber. Regardless of form, the autonomous underwater vehicle's mission remains the same: soar through ocean as efficiently as possible and collect data along the way.


Unlike standard profiling applications or shipboard surface sensors, AUVs combine a powerful blend of vertical profiling and horizontal surveys. This creates a unique data handling challenge however, as glider sensors must capture data on both temporal and spatial scales in dynamically changing environments.

## Case Study: SeaExplorer Endurance Record


As cruise ships toured the French Riviera, a SeaExplorer glider was hard at work beneath the waves. Completing a continuous 60 day, 1183 km mission on a single battery charge, the SeaExplorer set the record for the longest underwater glider voyage on a single battery charge. Unlike many other gliders that rely on disposable alkaline or lithium batteries, the SeaExplorer powers its flight and payload with Li-Ion rechargeable batteries to reduce operating costs and instrument downtime. Along for the marathon voyage was a Sea-Bird Glider Payload CTD (GPCTD), collecting high-resolution data throughout the voyage despite strict power considerations.

The SeaExplorer draws power from rechargeable Li-Ion batteries, opening doors for low-cost, fast turnaround missions. The glider was paired with a Sea-Bird Scientific Glider Payload CTD (GPCTD) and 43F dissolved oxygen sensor, conducting over 1,168 profiles of high-resolution CTD data despite a strict power budget.

Launched on September 5, 2013 from Cavalaire-sur-Mer, the SeaExplorer voyaged to Corsica and conducted several alternating trips



On November 5, 2013, LOV scientists recovered it for a total of 1,183 km travelled over 60 days with 18% of its batteries still remaining.





# CTDs Designed for Moving Platforms

By applying expertise in moored and profiling CTDs, Sea-Bird has designed instruments specifically for the unique sampling requirements of deployments on moving platforms, including AUVs, ROVs, and towed vehicles.

The GPCTD (left), Sea-Bird's flagship Glider CTD, sports an aerodynamic housing designed for easy integration with gliders. It is also useful on other vehicles—it has been a vital tool for some USV deployments, given its fast sampling capabilities, low power consumption, and native ability to incorporate a pump and oxygen sensor.



Along with CTDs designed for gliders, the SBE 49 FastCAT CTD is a miniaturization of typical profiling CTDs with a sampling speed and reduced form factor ideal for any applications that require rapid response time in a compact package. All of the SBE 49's sensors and pump are fully integrated in a lightweight and robust package, and a 16 Hz sampling speed provides ideal data quality for deployments on a moving platform.



## Optimizing CTD Data Quality

In a 2011 Case Study, Sea-Bird Scientific explored the requirements behind obtaining quality CTD data from a glider CTD. We found certain traits to be important, and incorporated them into the GPCTD and Slocum Glider CTD.

- Pumped flow fixes the response time of the temperature and conductivity sensors. While unpumped CTDs are susceptible to variable flow from inconsistent glider speeds, pumped CTDs have a known response time. The operator can correct for dynamic sampling errors that occur at temperature and salinity gradients, providing better computation of variables such as salinity and density.
- Ducted T-C sensors ensure that the temperature and conductivity sensors are measuring the same parcel of water
- Proper sampling rate ensures that the glider CTD is capturing temporal misalignments in temperature and conductivity sensors, and data is precise enough to capture small changes.



Uncorrected (left) and corrected (right) data from a Glider Payload CTD alongside a typical profiling CTD. Proper sampling rate, T-C temporal alignment, and cell thermal mass corrections provide significantly improved accuracy and resolution.



# Comparison: SUNA V2 and the Deep SUNA

Nitrate is often the macro-nutrient that limits primary productivity in the open ocean, and is often responsible for massive phytoplankton blooms when it flows out of rivers and streams into the coastal ocean. AUVs and ROVs outfitted with the Deep SUNA UV Nitrate sensor can be deployed to help understand nitrate dynamics in both the coastal and open oceans.

The SUNA V2 and Deep SUNA do the same thing—measure nitrate in water—with the same proven MBARI-ISUS nitrate measurement technology. Both have robust metal housings, and produce data that can be improved with the same temperature and salinity correction algorithm. So why does the SUNA V2 often reside in streams while the Deep SUNA explores the blue-ocean depths?

	SUNA V2	Deep SUNA
Similarities		
Wavelength Range	190-370 nm	190-370 nm
Lamp Type	Continuous Wave, Deuterium Lamp	Continuous Wave, Deuterium Lamp
Lamp Lifetime	900 hours	900 hours
Power Consumption	7.5 W (0.625 A at 12 V) nominal	7.5 W (0.625 A at 12 V) nominal
Accuracy	Dissolved oxygen	Dissolved oxygen
Differences		
Depth Rating	500 m	2000 m
Weight	5.1 kg	1.8 kg
Displacement	1749 cm <sup>3</sup>	1384 cm <sup>3</sup>
Material	Titanium	Anodized Aluminum
Calibration	Seawater and Freshwater	Seawater
Path Length	5 mm and 10 mm	10 mm

