

SBE 16plus V2 (RS-232) SEACAT Reference Sheet

(see SBE 16plus V2 [RS-232] User's Manual for complete details)

Sampling Modes

- **Autonomous sampling** - The 16plus V2 takes time series measurements once every 10 seconds to once every 4 hours, stores data in FLASH memory, and powers down between samples. Data can also be simultaneously transmitted real-time.
- **Polled sampling** – The 16plus V2 takes one sample. Depending on command used, the 16plus V2 can store data in FLASH memory and / or transmit data to computer.
- **Serial line sync** – The 16plus V2 wakes up, samples, stores data in FLASH memory, and powers off in response to a pulse on serial line. Depending on setup, the 16plus V2 can transmit data to computer. This provides an easy method for synchronizing 16plus V2 sampling with other instruments such as Acoustic Doppler Current Profilers (ADCPs) or current meters, without drawing on their battery or memory resources.

Communication Setup Parameters

1. Double click on SeatermV2.exe. SeatermV2 opens, select SBE 16plus V2 RS232. Seaterm232 opens.
2. In the Communications menu, select Configure. Select the Comm port and baud rate (factory set to 9600), and click OK.
3. Seaterm232 should automatically connect to the 16plus V2. As it connects, it sends **GetHD** and displays the response, and then fills the Send Commands window with the list of commands for your 16plus V2.

Deployment

1. Batteries:
 - A. *Remove battery end cap*: Wipe dry housing/end cap seam. Unthread end cap by rotating counter-clockwise. Wipe dry O-ring mating surfaces in housing with lint-free cloth.
 - B. *Remove and replace battery cover plate and batteries*: Remove three Phillips-head screws and washers from battery cover plate, and remove cover plate. Turn 16plus V2 over and remove batteries. Install new batteries, + terminals against flat contacts and - terminals against spring contacts. Align battery cover plate with housing. Reinstall three Phillips-head screws and washers, while pushing hard on battery cover plate to depress spring contacts at bottom of battery compartment.
 - C. *Reinstall battery end cap*: Remove water from O-rings and mating surfaces with lint-free cloth. Inspect O-rings and mating surfaces for dirt, nicks, and cuts. Clean/replace as necessary. Apply light coat of O-ring lubricant to O-ring and mating surfaces. Fit end cap into housing and rethread into place, using a wrench to ensure end cap is tightly secured.
2. Program 16plus V2 for intended deployment (see other side of this sheet for *Command Instructions and List*):
 - A. Send **DateTime=mmddyyyymmss** (month, day, year, hour, minute, second) to set date and time.
 - B. Ensure all data has been uploaded, and then send **InitLogging** to make entire memory available for recording. If **InitLogging** is not sent, data will be stored after last recorded sample.
 - C. Establish setup and sampling parameters. If desired, use **StartDateTime=** and **StartLater** to establish delayed start date and time.
3. Install a cable or dummy plug for each connector on 16plus V2 sensor end cap. Install a locking sleeve over each plug/cable connector. Connect other end of cables to appropriate sensors.
4. Verify hardware and external fittings are secure.
5. Remove Tygon tubing that is looped end-to-end around conductivity cell.
6. For Autonomous sampling: If not already done, send **StartNow** or send **StartDateTime=** and **StartLater**.

Command Instructions and List

- Input commands in upper or lower case letters and register commands by pressing Enter key.
- 16plus V2 sends an error message if an invalid command is entered.
- (if **OutputExecutedTag=N**) If 16plus V2 does not return S> prompt after executing a command, press Enter key to get S>.
- If new command is not received within 2 minutes after completion of a command, 16plus V2 returns to quiescent (sleep) state.
- If in quiescent (sleep) state, re-establish communications by clicking Connect in Communications menu or pressing Enter key.

Shown below are the commands used most commonly in the field. See the Manual for complete listing and detailed descriptions.

CATEGORY	COMMAND	DESCRIPTION
Status	GetCD	Get and display Configuration Data.
	GetSD	Get and display Status Data.
	GetCC	Get and display Calibration Coefficients.
	GetEC	Get and display Event Counters.
	ResetEC	Reset Event Counters.
	GetHD	Get and display Hardware Data.
	DS	Display status and setup parameters.
General Setup	DCal	Display calibration coefficients.
	DateTime=mmddyyhhmmss	Set real-time clock month, day, year, hour, minute, second.
	BaudRate=x	x= baud (600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200). Default 9600.
	Echo=x	x=Y: Echo characters as you type. x=N: Do not.
	OutputExecutedTag=x	x=Y: Display XML Executing and Executed tags. x=N: Do not.
	TxRealTime=x	x=Y: Output real-time data for autonomous sampling and serial line sync. x=N: Do not.
	PumpMode=x	x=0: No pump. x=1: Run pump for 0.5 seconds before each sample. x=2: Run pump during each sample.
	NCycles=x	x= number of measurements to take and average for every sample.
	InitLogging	After uploading data, initialize logging to make entire memory available for recording.
	SampleNumber=x	After uploading data, set SampleNumber=0 to make entire memory available for recording.
Pressure Sensor Setup <i>(internally mounted)</i>	HeaderNumber=x	x= header number for first header when sampling begins.
	QS	Place in quiescent (sleep) state. Logging and memory retention not affected.
	PType=x	x=0: No pressure. x=1: Strain gauge pressure sensor. x=3: Quartz pressure sensor with temperature compensation.
Voltage Sensor Setup	RefPress=x	x= reference pressure (gauge) in db to use if 16plus V2 does not include pressure sensor.
	ParosIntegration=x	x= integration time (seconds) for Quartz pressure sensor.
	Volt0=x Volt1=x Volt2=x Volt3=x Volt4=x Volt5=x	x=Y: Enable external voltage (voltage 0, 1, 2, 3, 4, and 5). x=N: Do not.
RS-232 Sensor Setup	DelayBeforeSampling=x	x= time (seconds) to wait after switching on external voltage before sampling.
	BioWiper=x	x=Y: Configuration includes ECO-FL fluorometer with Bio-Wiper. x=N: Does not.
	SBE38=x	x=Y: Enable SBE 38 secondary temperature sensor. x=N: Do not.
	SBE50=x	x=Y: Enable SBE 50 pressure sensor. x=N: Do not.
	GTD=x	x=Y: Enable GTD (Pro-Oceanus Gas Tension Device). x=N: Do not.
	DualGTD=x	x=Y: Enable dual (2) GTDs (Pro-Oceanus Gas Tension Devices). x=N: Do not.
Output Format	TGTD	Measure Gas Tension Device(s), output 1 converted data sample for each GTD.
	Optode=x	x=Y: Enable Aanderaa Optode. x=N: Do not.
	OutputFormat=x	x=0: Raw frequencies/voltages, Hex. x=1: Converted data, Hex. x=2: Raw frequencies/voltages, decimal. x=3: Converted data, decimal. x=4: Not valid format; do not use. x=5: Converted data, decimal, XML.
	OutputSal=x	x=Y: Output salinity (psu). x=N: Do not.
Autonomous Sampling (logging)	OutputSV=x	x=Y: Output sound velocity (m/sec). x=N: Do not.
	OutputUCSD=x	x=Y: Output sigma-t (kg/m ³), battery voltage, operating current (mA). x=N: Do not.
	SampleInterval=x	x = interval between samples (10 - 14,400 seconds).
	StartNow	Start autonomous sampling now.
	StartDateTime=mmddyyhhmmss	Delayed start: month, day, year, hour, minute, second.
Polled Sampling	StartLater	Start autonomous sampling at delayed start time.
	Stop	Stop autonomous sampling or waiting to start autonomous sampling. Press Enter key before entering command. Must stop sampling before uploading data.
	SL	Output last sample from buffer and leave power on.
	SLT	Output last sample from buffer, take new sample and store data in buffer. Leave power on.
	TS	Take sample, store in buffer, output data. Leave power on.
	TSS	Take sample, store in buffer and FLASH memory , output data, turn power off.
Serial Line Sync	TSSOn	Take sample, store in buffer and FLASH memory , output data, leave power on.
	GetLastSamples:x	Output last x samples from FLASH memory.
Data Upload	SyncMode=x	x=Y: Enable serial line sync mode. x=N: Do not.
	SyncWait=x	x= time (seconds) 16plus V2 monitors line for commands after taking sample in sync mode.
Data Upload	GetSamples:b,e or DDb,e	Upload data from scan b to e.
	GetHeaders:b,e or DHb,e	Upload headers from header b to e.