



SEA-BIRD
SCIENTIFIC



Thetis Profiler

Product #:

FAS-540591

USD Price:
Available

Contact Sea-Bird

Autonomous moored profiling platform

Thetis is a vertically profiling platform for use in coastal marine and fresh water environments. It samples the water column for distributions of physical, biological, chemical and optical properties at a fixed location over extended periods of time.

Modular, self-contained, winch-driven profiler

Greatly simplifies deployment, recovery and maintenance.

Integrated control, power, and telemetry systems

Comes with mooring controller, GPS and antenna, strobe, battery pack, and winch.

Sub-meter scale vertical resolution from 1–2 m above sea floor to the air-water interface.

Base system sensors include an SBE49 CTD, ECO bbFL2-w, and PAR.